



500 North 7th Street • Sanford, North Carolina 27331

P.O. Box 5410 • Sanford, North Carolina 27331

office: 919-774-7474 • fax: 919-774-7430

www.thisendup.com

Toolless Bed and Bunk Bed Assembly Instructions.

The toolless hook at the end of the side rail is designed to lock into place into the toolless rail installed into the head and footboards. The locking procedure is the same for the bed and bunk bed applications.

Bed Assembly

The bed is set up by dropping the hook assembly at the end of the side rail into the toolless rail in the bed end. The operation will go quicker and easier with two people but the bed can be assembled alone. The height or location of the side rail in the bed end is up to the customer preference. Of course the height must be level across the bed ends and from side to side. Place the ends of each side rail into the bed and repeat this for the other end. Move the bed to the final location. Using a 16oz rubber mallet firmly hammer down at the end of the side rail near the bed end to lock the hook into the hook assembly. This should be done at each corner and then repeated around the bed again. If the bed is moved this procedure must be repeated to ensure that the hooks remain firmly locked into the hook assembly.

Bunk Bed Assembly

Assemble the Headboards as you would the Bed. Next after mounting the footboards on top of the headboards with the 3/8" bed pins, drop in the side rail hook into the hook assembly at one end and then the other end. Do this for both sides. Once the bed is placed into its final location lock the assembly by once again hitting the top of the side rail firmly with the rubber mallet. Once again, if the bed is moved this procedure must be repeated to ensure that the hooks remain firmly locked into the hook assembly.

Disassembly

Bed disassembly is performed by hitting the bottom of the side rail with the rubber mallet near the bed end to unlock the hook assembly from the rail assembly.